

# Water Heater Conversion Component

## INSTALLATION INSTRUCTIONS

1. Remove the lower water heating element and replace with the pipe adapter labeled as "A".
2. Assemble the brass conversion section using thread sealant or teflon tape approved for use on water heaters.
3. Screw the brass assembly into the pipe adapter.
4. Plumb the drainback system into the conversion assembly so that the flow enters into the quick-connect fitting labeled as "B" and exits from the fitting labeled as "C".
5. The Y-strainer labeled as "D" is an optional component to prevent any tank buildup from entering the solar pump.

